

# **Life Support Systems Microbial Challenges**

**August 24, 2009**

**Monsi C. Roman  
NASA/ Marshall Space Flight Center  
ECLSS Chief Microbiologist  
(256)544-4071**

# Agenda

- **Environmental Control and Life Support Systems (ECLSS) What is it?**
- **A Look Inside the International Space Station (ISS)**
- **The Complexity of a Water Recycling System**
- **ISS Microbiology Acceptability Limits**
- **Overview of Current Microbial Challenges**
- **In a Perfect World What we Would Like to Have**
- **The Future**

# Environmental Control and Life Support Systems (ECLSS)

Control  
Atmosphere  
Pressure


Condition  
Atmosphere

Respond to  
Emergency  
Conditions



Control Internal  
CO<sub>2</sub> &  
Contaminants

Provide Water

Needs



Effluents




Development Complete






# Space Station Regenerative ECLSS Flow Diagram (Current Baseline)








# International Space Station ECLSS







# A Look Inside ISS







ISS008E22249



ISS003E8389 2001/12/15 02:02:09



# Living in Space




ISS007E06455

























**Filling up a bag of water in the Zvezda, SM**








# ISS Water Processor Diagram



# Water Processor Assembly



# ECLSS Microbial Challenges

- Wetted Materials in space life support systems include:
  - Titanium
  - 316L Stainless Steel
  - Teflon
  - Viton O-rings
  - Nickel-Brazed Stainless Steel

# ECLSS Microbial Challenges

## ISS Microbial Acceptability Limits (U.S.)

|          | Bacteria                                  | Fungi                       |
|----------|---|-----------------------------|
| Surfaces | 10,000 CFU/100 cm <sup>2</sup>            | 100 CFU/100 cm <sup>2</sup> |
| Water    | 100 CFU/ 100 ml (no detectable coliforms) | N/A                         |
| Air      | ≤ 1,000 CFU/m <sup>3</sup>                | 100 CFU/ m <sup>3</sup>     |

CFU/cm<sup>2</sup>= colony forming units per square centimeter; CFU/ m<sup>3</sup>= colony forming units per cubic meter;  
CFU/ ml= colony forming units per milliliter



•

•

•

•

•

•

•

•

•

•

•

•

•

# ECLS Microbial Challenges

- **Urine/Pretreated Urine**
  - Hardware Performance Issues
    - Control of biofilm on wetted surfaces
    - Control of fungal growth in pretreated urine
- **Water (potable/wastewater)**
  - Health and Hardware Performance/Life Issues
    - Control of biofilm on wetted surfaces
      - Conditions of flight equipment unknown
    - Control of microorganisms in potable water
      - Re-growth potential/resistance to antimicrobials/MIC
    - Control microorganisms in humidity condensate

# ECLS Microbial Challenges

- **Coolant**
  - Health and Hardware Performance/Life Issues
    - Control of microorganisms in the fluid
    - Control of biofilm on wetted surfaces
    - Microbiologically Influenced Corrosion (MIC)
- **Surfaces**
  - Health and Hardware Performance/Life Issues
    - Fungi, bacteria
- **Air**
  - Health and Hardware Performance/Life Issues
    - Fungi, bacteria



# **ECLSS Microbial Challenges (Design and Test)**

- Flow rates: low, intermittent or no flow**
- Dead-legs**
- Potential long term storage of water in Teflon bags**
- Limitations with the use of antimicrobials**
- Gravity/microgravity effects**
- Wastewater in narrow tubes**

# **ECLSS Microbial Challenges (Design and Test)**

- Holding time (between sample and analysis)**
- Limited monitoring technology available**
- Data interpretation**
- Acceptable levels of microorganisms/biofilm**
- Need for long term ground testing**
- Replicate applicable flight conditions to ground tests**





# ECLSS Microbial Challenges

## Challenges with monitoring ECLS systems in-flight include:

- Microbial count (quantification)
  - Viable vs non-viable
  - How will it compare with culture methods?
- Real-time identification
  - Bacteria, Fungi, Viruses
- Flexible
  - Integrated to systems (in-line)
  - Hand-held (for clinical applications)
- Robustness
  - Will the hardware survive <sup>31</sup>qual/acceptance testing?

# ECLSS Microbial Challenges

- If gene-base technology will be used what challenges, like damage to genetic material due to radiation, will need to be addressed?
- Expendables (how much waste will be generated)
- Consumables (reusable is preferred)
- Low power consumption
- Equipment size
- Non-hazardous reagents
- Non-generation of hazardous waste

# ECLSS Microbial Challenges


- Calibration (positive/negative controls?)
- Cleaning/disinfection of the sample collection areas
  - How to avoid cross contamination?
- What chemicals/conditions(temp, humidity, etc) could cause a problem (void the reaction)?
- Maintenance/repair (ORU's?)
- Construction materials
  - Are the materials acceptable in a close environment?



# ECLSS Microbial Challenges

- Sample size
- Detection limit (currently <300 CFU/100 mL)
- Microgravity sensitivity
- Sensitivity to particles/precipitates in the fluid
- A system that can be upgraded as needed is preferable (as “target” organisms are identified)
- Will the crew be able to “read” the results on-orbit; can the results be sent to the ground?
- Sample archival for later analyses





ISS006E16953





10000051000

